


HARDWARE PACK

TOOLS NEEDED FOR ASSEMBLY

- #2 Phillips screwdriver (long and short)
- 1/4" Slotted screwdriver (long and short)
- Adjustable wrench
- Pliers

No.	Description	Part Number	Qty.
1	1/4"-20UNCx50 Screw	20120-13050-250	2
2	1/4"-20UNCx38 Screw	20120-13038-250	6
3	1/4"-20UNCx16 Screw	20120-13016-250	34
4	1/4"-20UNC Screw	G353-0014-9000	4
5	NO.10-24UNC x13 Screw	20124-10013-250	15
6	ST4.8X10 Tapping Screw	22500-48010-810	2
7	NO.8-32 X 3/8, Philips Flat Head	20332-08010-250	3
8	ST4.2X10 Tapping Screw	22500-42010-137B	14
9	Rubberized Washer	G501-0054-9100	10
10	1/4"-20UNC Flange Nut	31220-13000-250	4
11	NO.10-24UNC Flange Nut	31224-10000-250	1
12	Wheel Lock Pin	G350-0026-9000	1

⚠ Caution:
Sheet metal can cause injury. Wear gloves when installing the grill.



BEFORE ASSEMBLING THIS BARBECUE, READ THE INSTRUCTIONS CAREFULLY.


Assemble the barbecue on a flat, clean surface. Grill is heavy. Two people are recommended to assemble this barbecue.

PARTS LIST G36323

Item No.	Qty.	Description	Part No.
AA	1	Top Lid Assembly	G363-6200-01
AA1	1	Top lid Left side panel	G532-0002-01
AA2	1	Top lid Right side panel	G532-0003-01
AB	1	Lid Handle	G363-0005-0A
AC	1	Thermometer	G363-0035-01
AD	1	Thermometer Bezel	G532-0006-01
AE	2	Screw, Top Lid	G466-0007-01
AF	2	Lid Bumper, Front	G527-0002-02
AG	2	Lid Bumper, Rear	G303-0038-01
BA	1	Burner Box Assembly	G363-3100-01
BB	2	Main Burner	G532-K200-01
BC	1	Carryover Assembly	G354-0024-01
BD	2	Heat Distribution Plate	G532-0016-01
BE	1	Grease Channel	G363-0012-01
BF	2	Cooking Grate	G532-0017-02
BG	1	Cleaning Tool	G532-0049-01
BH	1	Warming Rack	G363-0013-01
BI	1	Match Holder	G501-0068-01
BJ	1	Grease Channel Shield	G532-0063-01
BK	2	Main Burner Brace	G466-0047-01
BL	1	Griddle	G532-0088-01
CA	1	Manifold Assembly	G363-6500-01
CB	1	Regulator	G363-0033-01
CC	1	Electrode Set, Main Burner	G515-0067-01
CD	2	Control Knob	G532-3600-01
CE1	1	Electronic Ignition Assembly	G532-0019-0A
CE2	1	Ignition Battery Cover	G532-0019-02
CE3	1	Instastart™ Ignition Button	G532-0082-01
CE4	1	Ground Wire	G602-0024-03
CF	2	Knob Bezel	G363-0026-01
CG	1	Control Panel	G363-0034-01
CH	1	Door Support Rail	G363-5400-01
CI	1	Grease Cup, Burner Box	G416-0015-01
CJ	2	Grease Cup Rails	G466-0034-01
CK	1	Upper Back Panel	G363-0037-01
CL	1	Heat Shield	G363-0016-01

Item No.	Qty.	Description	Part No.
DA	2	Side Shelf Table	G363-7200-01
DB	1	Side Shelf Fascia, Left	G363-7300-01
DC	1	Side Shelf Table Rear Brace, Left	G363-1000-02
DD	1	Side Shelf Fascia, Right	G363-7500-01
DE	1	Side Shelf Table Rear Brace, Right	G537-1100-01
DF	2	Support bracket A, side shelf	G363-1300-01
DG	2	Support bracket B, side shelf	G363-1400-01
DH	2	Side Shelf Extension Table	G537-1200-01
DI	1	Grease Cup Holder, Flare-Free	G532-0031-02
DJ	1	Grease Cup, Flare-Free	G532-0031-02
EA	1	Cart Side Panel, Left	G363-6800-01
EB	1	Cart Side Panel, Right	G363-6900-01
EC	1	Door Assembly	G363-5800-01
ED	1	Door Handle	G363-0019-02
EE	1	Bottom Shelf	G363-6600-01
EF	2	Locking Castor	G350-0023-01
EG	2	Castor	G350-0024-01
EH	1	Door Magnet Assembly	G527-0037-01
EI	1	Left Heat Shield	G363-0038-01
EJ	1	Right Heat Shield	G363-0039-01
EK	1	Ignition Box	G363-0040-01
F1	1	Hardware Pack	G363-B023-01
F2	1	Assembly Manual	G363-M023-01
F3	1	Safe Use and Care Manual	G363-M023-02
F4	2	Tank Support	G362-0060-01
F5	1	Clump Weight	G651-0012-01

EXPLODED DIAGRAM FOR G36323



Extras		
Hardware Pack F1	Assembly Manual F2	Safe Use & Care Manual F3